11.CEILING RECESSED TYPE PACKAGED AIR-CONDITIONER

(Split system, Air to air)
heat pump type

Refrigerant R22 use models

FDTN308HEN-SB FDT308HEN-SB

308HES-SB 308HES-SB

408HES-SB 408HES-SB

FDTN258HEN-A

258HEP-A

Refrigerant R407C use models

FDTNP308HEN-SB

308HES-SB

408HES-SB

508HES-SB

CONTENTS

11.1 G	ENERAL INFORMATION	381
11.1.1	Specific features	381
11.1.2	How to read the model name	381
11.2 S	ELECTION DATA	382
11.2.1	Specifications	382
11.2.2	Range of usage & limitations	396
11.2.3	Exterior dimensions	397
11.2.4	Exterior appearance	403
11.2.5	Piping system	404
11.2.6	Selection chart	406
11.2.7	Noise level	409
11.3 E	LECTRICAL DATA	410
11.3.1	Electrical wiring	410
11.4 O	UTLINE OF OPERATION CONTROL BY MICROCOMPUTER	417
11.5 A	PPLICATION DATA	417
11.5.1	Installation of indoor unit	418
11.5.2	Installation of wired remote controller	421
11.5.3	Installation of outdoor unit	421
116 M	AINTENANCE DATA	421

11.1 GENERAL INFORMATION

11.1.1 Specific features

- (1) Less refrigerant charge amount due to use of double phase refrigerant flow system. The total refrigerant charge amount has been reduced by more than 50%.
- (2) The indoor outdoor interconnection signal wiring has been done away with. The microcomputer chip is installed in the indoor unit. There is no need for the unit to communicate between the outdoor and indoor units so the unit is more resistant to electromagnetic noise thus the incidence of microcomputer malfunction has been reduced. The compressor in the outdoor unit has its own self protection function, that reacts according to abnormal high pressure and excessive high temperature.
- (3) There are only five power lines between the outdoor and indoor unit. As no signal wire is used there is no need to separate the power line from the signal line. One cabtyre cable with 6 wires encased in one sheath is enough for conducting the wiring work between the outdoor unit and the indoor unit. This contributes to simpler wiring work in the field.
- (4) All air supply ports have auto swing louvers. The indoor fan motor has two speeds of high and low.
- (5) All models have service valves protruding from the outdoor unit for faster flare connection work in the field.


(6) Low sound level

Operating noise has been remarkably reduced due to adoption of the crescent turbo fan which cuts off wind-blowing noise and also console type of cabinet which is highly effective to protect vibration.

(7) 700mm high drain head

Adoption of drain pump with high drain head and high capacity (600cc/min) has made it possible to have maximum 700 mm(from below ceiling drain head.[In case 700mm drain head is required, set it up close to the unit. It is impossible to do piping on down slope.]

11.1.2 How to read the model name



11.2 SELECTION DATA

11.2.1 Specifications

- (1) Refrigerant R22 use models
 - (a) Wireless remote controller type Model FDTN308HEN-SB

_		Model	FDTN308	BHEN-SB	
Item			FDTN308H	FDC308HEN3B	
No	minal cooling capacity ⁽¹⁾	W	71	00	
Nominal heating capacity ⁽¹⁾		W	80	000	
Ро	wer source		1 Phase, 220	0/240V, 50Hz	
	Cooling input	kW	2.98	/3.18	
È	Running current (Cooling)	A	13.9/14.4		
<u> </u>	Power factor (Cooling)	%	97/92		
=	Heating input	kW	2.84/3.00		
≣	Running current (Heating)	A	13.3	/13.7	
Operation data	Power factor (Heating)	%	97.	/91	
2	Inrush current (L.R.A)	A	9	5	
	Noise level ⁽⁴⁾	dB(A)	Hi 41 Lo:35	52	
Ex	terior dimensions	mm	Unit 260 × 840 × 840	845 × 880 × 340	
	$ extstyle{ extstyle{Height}} imes extstyle{ extstyle{Width}} imes extstyle{ extstyle{Depth}}$		Panel $30 \times 950 \times 950$	040 \ 000 \ 040	
Ne	t weight	kg	30 (Unit:24 Panel:6)	74	
Re	frigerant equipment			GT-A5534EN41 × 1	
(Compressor type & Q'ty				
	Motor	kW	-	2.5	
	Starting method		-	Line starting	
Heat exchanger			Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigerant control			Capillary tube		
Re	frigerant		R	22	
	Quantity	kg	-	1.4 [Pre-charged up to the piping length of 5n	
Re	frigerant oil	l	-	1.45 (BARREL FREEZE 32SAM)	
De	frost control		MC controlled de-icer		
Hi	gh pressure control		High pressure switch		
Ai	handling equipment		Turbo fan × 1	Propeller fan \times 1	
]	Fan type & Q'ty		Turbo ran x r	Tropener fair × 1	
	Motor	W	30 × 1	55 × 1	
	Starting method		Line starting	Line starting	
	Air flow (Standard)	СММ	Hi:17 Lo:12	58	
	Fresh air intake		Available	_	
	Air filter, Q'ty		Long life filter ×1(washable)	_	
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ctric heater	W	_	33 (Crank case heater)	
Op	eration control				
(Operation switch		Wireless remote control switch	– (Indoor unit side)	
Ro	om temperature control		Thermostat by electronics	_	
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.	
			Frost protection thermostat.	Abnormal discharge temperature protection	
Installation data mm		mm	Liquid line: 69.52 (3/8") Gas line: 615.88 (5/8")		
Refrigerant piping size (in)		(in)	Ει γαία iiie. ψ9.52 (5/6)	ασο πιο. φτοιου (σ/ο)	
Connecting method			Flare	piping	
Ī	Orain hose		(Connectable with VP25)	-	
]	nsulation for piping		Necessary (both Liquid & Gas lines)		
Ac	cessories		Mounting kit. Wireless rer	note controller. Drain hose	
On	tional parts		Decorative Panel		

Notes $\ (1)$ The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 313 150010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 220/240V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTN308HES-SB

Model		Model	FDTN308HES-SB			
Ite	m		FDTN308H	FDC308HES3B		
No	ominal cooling capacity ⁽¹⁾	W	71	00		
Nominal heating capacity ⁽¹⁾ W		W	80	000		
Ро	ower source		3 Phase, 38	0/415V 50Hz		
Cooling input		kW	2.90	/2.96		
<u>.</u>	Running current (Cooling)	A	5.1/5.5			
Operation data?	Power factor (Cooling)	%	86/75			
	Heating input	kW	2.54/2.60			
ב ב	Running current (Heating)	A	4.6/4.8			
5	Power factor (Heating)	%	84,	/75		
)	Inrush current (L.R.A)	A	4	.5		
	Noise level ⁽⁴⁾	dB(A)	Hi:41 Lo:35	52		
Ex	terior dimensions	mm	Unit 260 × 840 × 840	845 × 880 × 340		
	Height $ imes$ Width $ imes$ Depth	"""	Panel $30 \times 950 \times 950$	045 × 880 × 340		
Ne	et weight	kg	30 (Unit:24 Panel:6)	74		
Re	efrigerant equipment		_	GT-A5534ES41 × 1		
	Compressor type & Q'ty			G1 A55512511 × 1		
	Motor	kW	-	2.5		
	Starting method		-	Line starting		
	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing		
Refrigerant control			Capillary tube			
Re	efrigerant		R22			
	Quantity	kg	-	1.4 [Pre-charged up to the piping length of 5m		
Re	efrigerant oil	l	-	1.45 (BARREL FREEZE 32SAM)		
De	efrost control		MC controlled de-icer			
Hi	gh pressure control		High pressure switch			
Αi	r handling equipment		Turbo fan × 1	Propeller fan × 1		
	Fan type & Q'ty		Turbo ran × r	Fropener ran × r		
	Motor	W	30×1	55 × 1		
	Starting method		Line starting	Line starting		
	Air flow (Standard)	СММ	Hi:17 Lo:12	58		
	Fresh air intake		Available	_		
	Air filter, Q'ty		Long life filter ×1(washable)	-		
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)		
Ele	ectric heater	W	-	33 (Crank case heater)		
Or	peration control					
	Operation switch		Wireless remote control switch	– (Indoor unit side)		
Ro	om temperature control		Thermostat by electronics	_		
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.		
			Frost protection thermostat.	Abnormal discharge temperature protection		
Ins	stallation data	mm	Liquid line: 40 52 (2/0/)	Gas line: 415 88 /5/9"\		
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")			
	Connecting method		Flare piping			
	Drain hose		(Connectable with VP25)	-		
	Insulation for piping		Necessary (both L	iquid & Gas lines)		
Ac	cessories		Mounting kit. Wireless remote controller. Drain hose			
On	otional parts		Decorati	ive Panel		

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stalluarus
Cooling	27°C	19°C	35°C	24°C	ISO-T1 JIS B8616
Heating	20°C	-	7°C	6°C	130-11 113 15010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTN408HES-SB

Model		FDTN408	BHES-SB		
Item			FDTN408H	FDC408HES3B	
No	minal cooling capacity ⁽¹⁾	W	100	000	
Nominal heating capacity ⁽¹⁾		W	112	200	
Ро	wer source		3 Phase, 380	0/415V 50Hz	
	Cooling input	kW	4.50/	4.60	
	Running current (Cooling)	A	7.8/	78.1	
ara	Power factor (Cooling)	%	88/79		
	Heating input	kW	3.88/3.92		
֝֟֟֝ <u>֟</u>	Running current (Heating)	A	7.1/7.5		
Operation data	Power factor (Heating)	%	83/73		
)	Inrush current (L.R.A)	A	5	3	
	Noise level ⁽⁴⁾	dB(A)	Hi: 48 Lo:40	54	
Ex	terior dimensions	mm	Unit 320 × 840 × 840	1050 × 920 × 340	
ı	Height $ imes$ Width $ imes$ Depth	mm	Panel $30 \times 950 \times 950$	1050 × 920 × 540	
Ne	t weight	kg	34 (Unit:28 Panel:6)	90	
Re	frigerant equipment			GU-A5550ES41 × 1	
(Compressor type & Q'ty		_	GO-A3330E341 × 1	
	Motor	kW	-	2.8	
	Starting method		_	Line starting	
ı	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigerant control			Capilla	ry tube	
Re	frigerant		R22		
(Quantity	kg	-	1.7 [Pre-charged up to the piping length of 5n	
Re	frigerant oil	l	-	1.6 (BARREL FREEZE 32SAM)	
De	frost control		MC controlled de-icer		
Hig	gh pressure control		High pressure switch		
Air	r handling equipment		Tools for v. 1	D 11	
I	Fan type & Q'ty		Turbo fan × 1	Propeller fan \times 2	
	Motor	W	80×1	40×2	
	Starting method		Line starting	Line starting	
-	Air flow (Standard)	СММ	Hi:26 Lo:19	70	
ı	Fresh air intake		Available	_	
1	Air filter, Q'ty		Long life filter ×1(washable)	-	
Sho	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ectric heater	W	_	40 (Crank case heater)	
Op	peration control				
(Operation switch		Wireless remote control switch	- (Indoor unit side)	
Ro	om temperature control		Thermostat by electronics	_	
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.	
			Frost protection thermostat.	Abnormal discharge temperature protection	
Ins	stallation data	mm			
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8")	Gas line: \$19.05 (3/4")	
Connecting method		Flare piping			
Drain hose			(Connectable with VP25)	-	
I	Insulation for piping		Necessary (both L	iquid & Gas lines)	
	cessories		Mounting kit. Wireless ren		
	tional parts		Decorative Panel		

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stallualus
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 313 150010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTN508HES-SB

Model		Model	FDTN508HES-SB			
Ite	m		FDTN508H	FDC508HES3B		
No	ominal cooling capacity ⁽¹⁾	W	125	500		
No	ominal heating capacity(1)	W	140	000		
Power source			3 Phase, 380	0/415V 50Hz		
	Cooling input	kW	5.30/	5.55		
È.	Running current (Cooling)	A	9.5/10.3			
Operation data?	Power factor (Cooling)	%	85/75			
=	Heating input	kW	4.85/4.98			
Ę	Running current (Heating)	A	9.0/9.9			
ě	Power factor (Heating)	%	82/	770		
)	Inrush current (L.R.A)	A	7-	4		
	Noise level ⁽⁴⁾	dB(A)	Hi:49 Lo:43	55		
Ex	terior dimensions	mm	Unit 320 × 840 × 840	1250 × 920 × 340		
	Height $ imes$ Width $ imes$ Depth	"""	Panel $30 \times 950 \times 950$	1230 \ 920 \ 340		
Ne	et weight	kg	36 (Unit:30 Panel:6)	101		
Re	efrigerant equipment		_	GU-A5570ES41 × 1		
	Compressor type & Q'ty			G0 A00702011 × 1		
	Motor	kW	-	3.75		
	Starting method		-	Line starting		
	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing		
Refrigerant control			Capillary tube			
Re	efrigerant		R22			
	Quantity	kg	-	1.9 [Pre-charged up to the piping length of 5m		
Re	efrigerant oil	l	-	1.6 (BARREL FREEZE 32SAM)		
De	efrost control		MC controlled de-icer			
Hi	gh pressure control		High pressure switch			
Αi	r handling equipment		Turbo fan × 1	Promollon for y 2		
	Fan type & Q'ty		Turbo ran × 1	Propeller fan $\times 2$		
	Motor	W	130×1	65×2		
	Starting method		Line starting	Line starting		
	Air flow (Standard)	СММ	Hi:28 Lo:20	110		
	Fresh air intake		Available	-		
	Air filter, Q'ty		Long life filter ×1(washable)	-		
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)		
Ele	ectric heater	W	_	40 (Crank case heater)		
Or	peration control					
	Operation switch		Wireless remote control switch	- (Indoor unit side)		
Ro	om temperature control		Thermostat by electronics			
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.		
			Frost protection thermostat.	Abnormal discharge temperature protection		
Ins	stallation data	mm	Liquid line: AQ EQ (2/0/\)	Gas line: #19.05 (3///^)		
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8") Gas line: φ19.05 (3/4")			
Connecting method			Flare p	oiping		
	Drain hose		(Connectable with VP25)	-		
	Insulation for piping		Necessary (both L	iquid & Gas lines)		
Ac	cessories		Mounting kit. Wireless ren	note controller. Drain hose		
On	otional parts		Decorati	ve Panel		

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stallualus
Cooling	27°C	19°C	35°C	24°C	ISO-T1. JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 113 150010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTN258HEN-A

Model			FDTN258HEN-A		
Item			FDTN258H	FDC256HEN3A	
	ominal cooling capacity ⁽¹⁾	W		00	
	ominal heating capacity(1)	W		00	
Po	ower source		·	0/240V, 50Hz	
	Cooling input	kW	2.59		
	Running current (Cooling)	A	12.6/13.2		
g	Power factor (Cooling)	%	93/83		
5	Heating input	kW	2.38	/2.42	
2	Running current (Heating)	A	11.6	/12.2	
Operation data	Power factor (Heating)	%	93,	/83	
,	Inrush current (L.R.A)	A	6	4	
	Noise level ⁽⁴⁾	dB(A)	Hi: 39 Lo: 35	57	
Ex	terior dimensions	mm	Unit 260 \times 840 \times 840	615 × 850 × 290 + 30	
	$Height \times Width \times Depth$		Panel $30 \times 950 \times 950$	0.0 / 0.0 / 200 i 00	
Ne	et weight	kg	30 (Unit:24 Panel:6)	57	
Refrigerant equipment			_	RC5527ENE1 × 1	
	Compressor type & Q'ty			3333021 2.321 1.13	
Motor		kW	_	1.87	
Starting method			-	Line starting	
	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigerant control			Capillary tube		
Re	efrigerant		R22		
	Quantity	kg	-	1.25 [Pre-charged up to the piping length of 5m	
Re	efrigerant oil	l	-	1.63 (SUNISO 3GS)	
De	efrost control		IC control	led de-icer	
Hi	gh pressure control		High pressure regulator valve		
Αi	r handling equipment		Tools for v. 1	D 11	
	Fan type & Q'ty		Turbo fan × 1	Propeller fan \times 1	
	Motor	W	25×1	55×1	
	Starting method		Line starting	Line starting	
	Air flow (Standard)	СММ	Hi:16 Lo:11	42	
	Fresh air intake		Available	-	
	Air filter, Q'ty		Long life filter ×1(washable)	_	
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ectric heater	W	_	40 (Crank case heater)	
O	peration control				
-	Operation switch		Wireless remote control switch	– (Indoor unit side)	
	oom temperature control		Thermostat by electronics	-	
	afety equipment		Internal thermostat for fan motor.	Internal protector for compressor.	
	- • •		Frost protection thermostat.	Internal thermostat for fan motor. Internal pressure relief valve for compressor	
Ins	stallation data	mm	·		
Refrigerant piping size (in)		Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")			
Connecting method			Flare piping		
	Drain hose	(Connectable with VP25) –			
	Insulation for piping		Necessary (both Liquid & Gas lines)		
		1	Mounting kit. Wireless remote controller. Drain hose		
	ccessories		Mounting kit Wireless rer	note controller. Drain hose	

Notes $\ (1)$ The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	12°C	7°C	6°C	130-11, 113 150010

- (2) This packaged air conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR CONDITIONERS"
- (3) The operation data indicate when the air conditioner is operated at 220V and 240V respectively.
- (4) Indicates the value at mild mode.

Model FDTN258HEP-A

			Model	FDTN25	8HEP-A	
Item			Wiodei	FDTN258H	FDC256HEP3A	
Nominal co	ooling capacity(1)	ISO-T1			200	
		ISO-T3	W	52	000	
Nominal he	eating capacity(1)	ISO-T1	W	6400		
Power soul	rce			1 Phase, 2	220V, 60Hz	
Co	Cooling input			2.	68	
Ru	nning current (Cooling	g)	A	12	2.4	
-	wer factor (Cooling)		%	9	8	
He SO He	ating input		kW	2.	47	
Ru	nning current (Heating	g)	A	11	1.7	
Operation data® Ru Po Co Ru Ru Ru Po Ru	wer factor (Heating)		%	9	06	
er က Co	oling input		kW	3.	06	
O Ru	nning current (Cooling	g)	A	14	1.4	
<u>o</u> Po	wer factor (Cooling)		%	9	7	
Inrush c	urrent (L.R.A)		A	6	66	
Noise le	evel ⁽⁴⁾		dB(A)	Hi:39 Lo:35	57	
Exterior dia	mensions			Unit 260 × 840 × 840	615 × 850 × 200 × 20	
Height \times	Width × Depth		mm	Panel $30 \times 950 \times 950$	615 × 850 × 290 + 30	
Net weight			kg	30 (Unit:24 Panel:6)	57	
Refrigerant	equipment				RC5528EPE1 × 1	
Compres	sor type & Q'ty			-	NC3526EFET X I	
Motor			kW	_	1.68	
Starting	Starting method			_	Line starting	
Heat exc	hanger			Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigeran	t control			Capilla	ry tube	
Refrigerant	Ì			R	22	
Quantity			kg	-	1.25 [Pre-charged up to the piping length of 5m]	
Refrigerant	toil		l	_	1.63 (SUNISO 3GS)	
Defrost contr	ol			IC control	led de-icer	
High pressur	e control			High pressure regulator valve		
Air handlin	g equipment					
Fan type &	ċ Q'ty			Turbo fair × 1	Propeller fan × 1	
Motor			W	25×1	55×1	
Starting	method			Line starting	Line starting	
Air flow (Standard)		СММ	Hi:16 Lo:11	44	
Fresh air	intake			Available	-	
Air filter,	Q'ty			Long life filter ×1(washable)	-	
Shock & vib	ration absorber			Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Electric heate	er		W	_	40 (Crank case heater)	
Operation (control					
Operation switch			Wireless remote control switch	– (Indoor unit side)		
Room temperature control			Thermostat by electronics	_		
Safety equipment			Internal thermostat for fan motor.	Internal protector for compressor. Internal thermostat for fan motor.		
				Frost protection thermostat.	Internal pressure relief valve for compressor.	
Installation data		mm	Liquid line: 60 52 (2/9/\)	Gas line: #15 99 (5/9")		
Refrigerant piping size		(in)	Liquia line: φ9.52 (3/8°)	Gas line: \(\psi 15.88 \) (5/8")		
Connecting method				Flare	piping	
Drain ho	se			(Connectable with VP25)	-	
Insulation	for piping			Necessary (both L	iquid & Gas lines)	
Accessories				Mounting kit. Wireless rer	note controller. Drain hose	
Optional parts				Decorati	ive Panel	

Notes (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	150-11, 115 15010
Cooling	29°C	19°C	46°C	24°C	ISO-T3, SASO

- $(2) \ This packaged air conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR CONDITIONERS"$
- (3) The operation data indicate when the air conditioner is operated at 220V.
- (4) Indicates the value at mild mode.

(b) Wired remote controller type Model FDT308HEN-SB

		Model	FDT308	HEN-SB		
Item			FDT308-A	FDC308HEN3B		
No	ominal cooling capacity ⁽¹⁾	W	71	00		
No	ominal heating capacity(1)	W	80	00		
Ро	wer source		1 Phase, 220	0/240V, 50Hz		
Cooling input		kW	2.98/3.18			
9	Running current (Cooling)	A	13.9/14.4			
ata	Power factor (Cooling)	%	97/92			
r o	Heating input	kW	2.84/3.00			
atic	Running current (Heating)	A	13.3/13.7			
Operation data ^⑶	Power factor (Heating)	%	97/91			
0	Inrush current (L.R.A)	A	9	5		
	Noise level ⁽⁴⁾	dB(A)	Hi 41 Lo:35	52		
Ex	terior dimensions	mm	Unit 260 × 840 × 840	845 × 880 × 340		
ı	Height $ imes$ Width $ imes$ Depth	"""	Panel $30 \times 950 \times 950$	043 \ 000 \ 340		
Ne	et weight	kg	30 (Unit:24 Panel:6)	74		
Re	frigerant equipment		_	GT-A5534EN41 × 1		
(Compressor type & Q'ty			G1 A000 IENTI X I		
	Motor	kW	-	2.5		
	Starting method		-	Line starting		
Heat exchanger			Louver fins & inner grooved tubing	Slitted fins & bare tubing		
Refrigerant control			Capillary tube			
Re	efrigerant		R22			
(Quantity	kg	-	1.4 [Pre-charged up to the piping length of 5m		
Re	frigerant oil	l	-	1.45 (BARREL FREEZE 32SAM)		
De	frost control		MC controlled de-icer			
Hig	gh pressure control		High pressure switch			
Aiı	r handling equipment		Turbo fan × 1	Propeller fan × 1		
]	Fan type & Q'ty		Turbo ran × 1	1 Topener Tall × T		
	Motor	W	30×1	55 × 1		
	Starting method		Line starting	Line starting		
-	Air flow (Standard)	СММ	Hi:17 Lo:12	58		
ı	Fresh air intake		Available	1		
1	Air filter, Q'ty		Long life filter ×1(washable)	1		
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)		
Ele	ectric heater	W	-	33 (Crank case heater)		
Op	peration control		Wired remote control switch			
(Operation switch		(Optional : RCD-H-S-E)	- (Indoor unit side)		
Ro	om temperature control		Thermostat by electronics			
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.		
			Frost protection thermostat.	Abnormal discharge temperature protection		
Ins	stallation data	mm	Liquid lines 40 EQ (2/9/)	Gas line: 415 99 (5/9")		
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")			
	Connecting method		Flare piping			
	Drain hose		(Connectable with VP25)	-		
]	Insulation for piping		Necessary (both L	iquid & Gas lines)		
Ac	cessories		Mounting kit	t. Drain hose		
Op	tional parts		Decorative Panel			

Notes (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 113 150010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 220/240V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDT308HES-SB

Model		Model	FDT308HES-SB			
Ite	m		FDT308-A	FDC308HES3B		
No	ominal cooling capacity ⁽¹⁾	W	71	00		
No	ominal heating capacity ⁽¹⁾	W	80	00		
Po	ower source		3 Phase, 38	0/415V 50Hz		
Cooling input		kW	2.90/2.96			
<u>.</u>	Running current (Cooling)	A	5.1/5.5			
פום	Power factor (Cooling)	%	86/75			
=	Heating input	kW	2.54/2.60			
į	Running current (Heating)	A	4.6/4.8			
Operation data?	Power factor (Heating)	%	84/75			
)	Inrush current (L.R.A)	A	4	5		
	Noise level ⁽⁴⁾	dB(A)	Hi:41 Lo:35	52		
Ex	terior dimensions	mm	Unit 260 × 840 × 840	845 × 880 × 340		
	$ extsf{Height} imes extsf{Width} imes extsf{Depth}$	"""	Panel $30 \times 950 \times 950$	043 \ 000 \ 340		
Ne	et weight	kg	30 (Unit:24 Panel:6)	74		
Re	efrigerant equipment			GT-A5534ES41 × 1		
	Compressor type & Q'ty			G.17.6551=5117X.1		
	Motor	kW	-	2.5		
	Starting method		-	Line starting		
Heat exchanger			Louver fins & inner grooved tubing	Slitted fins & bare tubing		
Refrigerant control			Capillary tube			
Re	efrigerant		R	22		
	Quantity	kg	-	1.4 [Pre-charged up to the piping length of 5m		
Re	efrigerant oil	l	-	1.45 (BARREL FREEZE 32SAM)		
De	efrost control		MC controlled de-icer			
	gh pressure control		High press	sure switch		
Αi	r handling equipment		Turbo fan × 1	Propeller fan × 1		
	Fan type & Q'ty		Turbo ran × 1	1 topener fail × f		
	Motor	W	30 ×1	55 × 1		
	Starting method		Line starting	Line starting		
	Air flow (Standard)	СММ	Hi:17 Lo:12	58		
	Fresh air intake		Available	_		
	Air filter, Q'ty		Long life filter ×1(washable)	_		
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)		
Ele	ectric heater	W	_	33 (Crank case heater)		
Or	peration control		Wired remote control switch			
	Operation switch		(Optional : RCD-H-S-E)	– (Indoor unit side)		
Ro	oom temperature control		Thermostat by electronics	-		
Sa	efety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.		
			Frost protection thermostat.	Abnormal discharge temperature protection		
Ins	stallation data	mm	jauid line: 49 52 /2/9"\	Gas line: 415 88 (5/8″)		
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")			
	Connecting method		Flare	piping		
	Drain hose		(Connectable with VP25)	_		
-	Insulation for piping		Necessary (both L	iquid & Gas lines)		
Ac	ecessories		Mounting ki	t. Drain hose		
On	otional parts		Decorative Panel			

Notes (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stalluarus
Cooling	27°C	19°C	35°C	24°C	ISO-T1 JIS B8616
Heating	20°C	-	7°C	6°C	130-11 113 00010

- (2) This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"
- (3) The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.
- (4) Indicates the value at mild mode.

Model FDT408HES-SB

Model		FDT408HES-SB			
Iten			FDT408-A	FDC408HES3B	
Nor	ninal cooling capacity ⁽¹⁾	W	100	000	
Nor	ninal heating capacity(1)	W	112	200	
Pov	ver source		3 Phase, 380	0/415V 50Hz	
	Cooling input	kW	4.50/	4.60	
2	Running current (Cooling)	A	7.8/8.1		
ata	Power factor (Cooling)	%	88/79		
Operation data	Heating input	kW	3.88/3.92		
	Running current (Heating)	A	7.1/7.5		
je je	Power factor (Heating)	%	83/73		
7	Inrush current (L.R.A)	A	5	3	
Ī	Noise level ⁽⁴⁾	dB(A)	Hi: 48 Lo:40	54	
Ext	erior dimensions		Unit 320 × 840 × 840	4050 000 040	
Н	$eight \times Width \times Depth$	mm	Panel $30 \times 950 \times 950$	$1050\times920\times340$	
Net	weight	kg	34 (Unit:28 Panel:6)	90	
Ref	rigerant equipment			GU-A5550ES41 × 1	
С	ompressor type & Q'ty		_	GO-A5550E541 × 1	
	Motor	kW	-	2.8	
	Starting method		_	Line starting	
Н	eat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigerant control			Capillary tube		
Ref	rigerant		R22		
G	uantity	kg	-	1.7 [Pre-charged up to the piping length of 5m	
Ref	rigerant oil	l	-	1.6 (BARREL FREEZE 32SAM)	
Def	rost control		MC controlled de-icer		
Hig	h pressure control		High pressure switch		
Air	handling equipment		m	D 11 C 2	
F	an type & Q'ty		Turbo fan \times 1	Propeller fan \times 2	
	Motor	W	80×1	40×2	
	Starting method		Line starting	Line starting	
Α	ir flow (Standard)	СММ	Hi:26 Lo:19	70	
F	resh air intake		Available	_	
A	ir filter, Q'ty		Long life filter ×1(washable)	_	
Sho	ck & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Elec	etric heater	W	_	40 (Crank case heater)	
Оре	eration control		Wired remote control switch	*	
O	peration switch		(Optional : RCD-H-S-E)	- (Indoor unit side)	
	m temperature control		Thermostat by electronics	_	
Saf	ety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.	
			Frost protection thermostat.	Abnormal discharge temperature protection	
Inst	tallation data	mm	·		
Refrigerant piping size (in)		(in)	Liquid line: φ9.52 (3/8") Gas line: φ19.05 (3/4")		
	Connecting method		Flare _l	piping	
D	rain hose		(Connectable with VP25)	_	
	sulation for piping		Necessary (both L	iquid & Gas lines)	
Ir			Mounting kit. Drain hose		
	essories		Mounting kit	t. Drain hose	

Notes (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stalldards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	13O-11, JIS D0010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDT508HES-SB

	Model		FDT508HES-SB			
Ite	m		FDT508-A	FDC508HES3B		
Nominal cooling capacity ⁽¹⁾ W		125	500			
No	ominal heating capacity ⁽¹⁾	W	140			
Po	ower source		3 Phase, 380	0/415V 50Hz		
Cooling input		kW	5.30/5.55			
_	Running current (Cooling)	A	9.5/10.3			
Operation data?	Power factor (Cooling)	%	85/75			
5	Heating input	kW	4.85/4.98			
	Running current (Heating)	A	9.0/9.9			
<u> </u>	Power factor (Heating)	%	82/70			
)	Inrush current (L.R.A)	A	7-	4		
	Noise level ⁽⁴⁾	dB(A)	Hi:49 Lo:43	55		
Ex	terior dimensions	mm	Unit 320 × 840 × 840	1250 × 920 × 340		
	Height $ imes$ Width $ imes$ Depth		Panel $30 \times 950 \times 950$	1250 × 520 × 640		
	et weight	kg	36 (Unit:30 Panel:6)	101		
Re	efrigerant equipment		_	GU-A5570ES41 × 1		
-	Compressor type & Q'ty					
	Motor	kW	-	3.75		
	Starting method		_	Line starting		
Heat exchanger			Louver fins & inner grooved tubing	Slitted fins & bare tubing		
Refrigerant control			Capillary tube			
Re	efrigerant		R22			
	Quantity	kg	_	1.9 [Pre-charged up to the piping length of 5m		
Re	efrigerant oil	l	-	1.6 (BARREL FREEZE 32SAM)		
De	efrost control		MC control	lled de-icer		
Hi	gh pressure control		High pressure switch			
Αi	r handling equipment		Turbo fan × 1	Propeller fan \times 2		
	Fan type & Q'ty		Turbo ran × 1	1 Topener Tan × 2		
	Motor	W	130×1	65×2		
	Starting method		Line starting	Line starting		
	Air flow (Standard)	СММ	Hi:28 Lo:20	110		
	Fresh air intake		Available	_		
	Air filter, Q'ty		Long life filter ×1(washable)	-		
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)		
Ele	ectric heater	W	-	40 (Crank case heater)		
Op	peration control		Wired remote control switch			
	Operation switch		(Optional : RCD-H-S-E)	- (Indoor unit side)		
Ro	om temperature control		Thermostat by electronics			
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.		
			Frost protection thermostat.	Abnormal discharge temperature protection		
Ins	stallation data	mm	Liquid line: φ9.52 (3/8")	Gas line: 419.05 (3/4")		
Refrigerant piping size (in)		Liquiu IIIIe. ψ3.32 (3/6)	αα3 inie. ψ13.03 (0/4)			
	Connecting method		Flare piping			
	Drain hose		(Connectable with VP25)			
	Insulation for piping		Necessary (both L	iquid & Gas lines)		
Ac	cessories		Mounting kit	Drain hose		
On	otional parts		Decorati	ve Panel		

Notes (1) The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stallualus
Cooling	27°C	19°C	35°C	24°C	ISO-T1. JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 113 150010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

(2) Refrigerant R407C use models

Model FDTNP308HEN-SB

Model		FDTNP308HEN-SB			
Item		FDTN308H	FDCP308HEN3B		
No	minal cooling capacity ⁽¹⁾	W	71	00	
No	minal heating capacity ⁽¹⁾	W	80	00	
Po	wer source		1 Phase, 220	0/240V, 50Hz	
	Cooling input	kW	3.21/3.36		
	Running current (Cooling)	A	14.9/15.3		
Operation data	Power factor (Cooling)	%	98/92		
	Heating input	kW	2.96/3.10		
d	Running current (Heating)	A	13.9/14.3		
ber	Power factor (Heating)	%	97/90		
o	Inrush current (L.R.A)	A	9.	5	
İ	Noise level ⁽⁴⁾	dB(A)	Hi 41 Lo:35	52	
Ex	terior dimensions	mm	Unit 260 × 840 × 840	845 × 880 × 340	
ŀ	Height $ imes$ Width $ imes$ Depth	"""	Panel $30 \times 950 \times 950$	043 × 000 × 340	
Ne	t weight	kg	30 (Unit:24 Panel:6)	76	
Re	frigerant equipment		_	GT-A5534HN41 × 1	
(Compressor type & Q'ty		_	G1-A000411141 × 1	
	Motor	kW	-	2.5	
	Starting method		-	Line starting	
H	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
Refrigerant control			Capillary tube		
Re	frigerant		R407C		
(Quantity	kg	-	1.75 [Pre-charged up to the piping length of 5r	
Re	frigerant oil	l	-	1.45 (MA32)	
Def	frost control		MC controlled de-icer		
Hig	gh pressure control		High pressure switch		
Air	r handling equipment		There has four yell	D11	
F	Fan type & Q'ty		Turbo fan × 1	Propeller fan \times 1	
	Motor	W	30×1	55 × 1	
	Starting method		Line starting	Line starting	
1	Air flow (Standard)	СММ	Hi:17 Lo:12	58	
F	Fresh air intake		Available	_	
A	Air filter, Q'ty		Long life filter ×1(washable)	_	
Sho	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ectric heater	W	-	33 (Crank case heater)	
Op	eration control				
(Operation switch		Wireless remote control switch	- (Indoor unit side)	
Roo	om temperature control		Thermostat by electronics	-	
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.	
			Frost protection thermostat.	Abnormal discharge temperature protection High pressure switch for protection.	
Ins	stallation data	mm	-		
F	Refrigerant piping size	(in)	Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")		
	Connecting method		Flare	piping	
	Drain hose		(Connectable with VP25)		
I	Insulation for piping		Necessary (both L	iquid & Gas lines)	
	cessories		Mounting kit. Wireless ren		
	tional parts		Decorati		

Notes $\ (1)$ The data are measured at the following conditions.

Item	Indoor air temperature		Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1. JIS B8616
Heating	20°C	ı	7°C	6°C	130-11, 113 150010

 $^{(2) \} This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"$

⁽³⁾ The operation data indicate when the air-conditioner is operated at 220/240V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTNP308HES-SB

Model		FDTNP308HES-SB			
Ite			FDTN308H	FDCP308HES3B	
No	ominal cooling capacity ⁽¹⁾	W	71	00	
No	ominal heating capacity(1)	W	80		
Po	ower source		3 Phase, 380	0/415V 50Hz	
Cooling input		kW	3.13/3.28		
	Running current (Cooling)	A	5.5/5.8		
אַ די	Power factor (Cooling)	%	86/79		
5	Heating input	kW	2.98/3.12		
5	Running current (Heating)	A	5.5/5.8		
Operation data	Power factor (Heating)	%	82/75		
ر	Inrush current (L.R.A)	A	4	5	
	Noise level ⁽⁴⁾	dB(A)	Hi:41 Lo:35	52	
Ex	terior dimensions	mm	Unit 260 × 840 × 840	$845 \times 880 \times 340$	
	$Height \times Width \times Depth$		Panel 30 × 950 × 950		
Ne	et weight	kg	30 (Unit:24 Panel:6)	76	
Re	efrigerant equipment		_	GT-A5534HS41 × 1	
	Compressor type & Q'ty				
	Motor	kW	_	2.5	
	Starting method		_	Line starting	
	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
	Refrigerant control		Capillary tube		
Re	efrigerant		R407C		
	Quantity	kg	_	1.75 [Pre-charged up to the piping length of 5n	
Re	efrigerant oil	l	_	1.45 (MA32)	
De	efrost control		MC controlled de-icer		
Hi	gh pressure control		High pressure switch		
Αi	r handling equipment		Turbo fan × 1	Propeller fan × 1	
	Fan type & Q'ty		Turbo ran × 1	1 topener fail × f	
	Motor	W	30 ×1	55 × 1	
	Starting method		Line starting	Line starting	
	Air flow (Standard)	СММ	Hi:17 Lo:12	58	
	Fresh air intake		Available	-	
	Air filter, Q'ty		Long life filter ×1(washable)	-	
Sh	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ectric heater	W	-	40 (Crank case heater)	
Or	peration control				
	Operation switch		Wireless remote control switch	- (Indoor unit side)	
Ro	oom temperature control		Thermostat by electronics		
Sa	rfety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor. Abnormal discharge temperature protection	
			Frost protection thermostat.	Abnormal discharge temperature protection High pressure switch for protection.	
Ins	stallation data	mm	Liquid line: 40 E2 (2/0/)	Gas line: ±15.88 (5/9")	
Refrigerant piping size (in)		Liquid line: φ9.52 (3/8") Gas line: φ15.88 (5/8")			
	Connecting method	nnecting method		oiping	
	Drain hose		(Connectable with VP25)		
	Insulation for piping		Necessary (both L	iquid & Gas lines)	
Ac	ccessories		Mounting kit. Wireless ren	note controller. Drain hose	
$\overline{}$	otional parts		Decorati	ve Panel	

Notes $\ (1)$ The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stalluarus
Cooling	27°C	19°C	35°C	24°C	ISO-T1 JIS B8616
Heating	20°C	-	7°C	6°C	130-11 113 00010

- (2) This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"
- (3) The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.
- (4) Indicates the value at mild mode.

Model FDTNP408HES-SB

		Model	FDTNP40	8HES-SB	
Iteı			FDTN408H	FDCP408HES3B	
No	minal cooling capacity ⁽¹⁾	W	100	000	
No	ominal heating capacity(1)	W	112	200	
Ро	wer source		3 Phase, 380	0/415V 50Hz	
	Cooling input	kW	4.55/4.67		
2	Running current (Cooling)	A	8.0/8.4		
Power factor (Cooling) Heating input Running current (Heating) Power factor (Heating)		%	86/77		
5	Heating input	kW	4.39/4.51		
Running current (Heating)		A	7.6/8.4		
Power factor (Heating)		%	88/75		
ِ	Inrush current (L.R.A)	A	5	3	
	Noise level ⁽⁴⁾	dB(A)	Hi: 48 Lo:40	54	
Ex	terior dimensions	mm	Unit 320 \times 840 \times 840	1050 × 920 × 340	
ı	Height × Width × Depth		Panel 30 × 950 × 950	1000 / 020 / 010	
	t weight	kg	34 (Unit:28 Panel:6)	98	
Re	frigerant equipment		_	GU-A5550HS41 × 1	
(Compressor type & Q'ty				
	Motor	kW	-	2.8	
	Starting method		-	Line starting	
I	Heat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
I	Refrigerant control		Capillary tube		
Re	frigerant		R407C		
	Quantity	kg	-	2.12 [Pre-charged up to the piping length of 5m	
Refrigerant oil		l	-	1.6 (MA32)	
De	frost control		MC control	lled de-icer	
Hig	gh pressure control		High press	sure switch	
Air	r handling equipment		Turbo fan \times 1	Propeller fan × 2	
I	Fan type & Q'ty		Turbo run x r	Tropener ran × 2	
	Motor	W	80 × 1	40×2	
	Starting method		Line starting	Line starting	
1	Air flow (Standard)	СММ	Hi:26 Lo:19	70	
ı	Fresh air intake		Available	_	
1	Air filter, Q'ty		Long life filter ×1(washable)	-	
Sho	ock & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Ele	ectric heater	W	_	40 (Crank case heater)	
Op	peration control				
(Operation switch		Wireless remote control switch	– (Indoor unit side)	
Ro	om temperature control		Thermostat by electronics	_	
Sa	fety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor. Abnormal discharge temperature protection.	
			Frost protection thermostat.	High pressure switch for protection.	
Ins	stallation data	mm	Liquid line: 	Gas line: 619.05 (3/4")	
I	Refrigerant piping size	(in)	Ει γαία ίπο. φοίο Σ (0/0)	ΔΔ2οι φ10.00 (σ/ τ)	
	Connecting method		Flare _l	piping	
I	Drain hose		(Connectable with VP25)	_	
I	Insulation for piping		Necessary (both L	iquid & Gas lines)	
Ac	cessories		Mounting kit. Wireless ren	note controller. Drain hose	
On	tional parts		Decorati	ve Panel	

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Standards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 313 00010

⁽²⁾ This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"

⁽³⁾ The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.

⁽⁴⁾ Indicates the value at mild mode.

Model FDTNP508HES-SB

		Model	FDTNP50	8HES-SB	
Iten	n		FDTN508H	FDCP508HES3B	
Nor	minal cooling capacity ⁽¹⁾	W	129	500	
Noi	minal heating capacity ⁽¹⁾	W	14	000	
Pov	wer source		3 Phase, 38	0/415V 50Hz	
	Cooling input	kW	5.41/5.48		
2	Running current (Cooling)	A	9.7/10.0		
ata	Power factor (Cooling)	%	84	/76	
Heating input		kW	5.29/5.36		
Running current (Heating)		A	9.6	/9.9	
Power factor (Cooling) Heating input Running current (Heating) Power factor (Heating) Power factor (Heating)		%	83.	/75	
> [Inrush current (L.R.A)	A	7	4	
Ī	Noise level ⁽⁴⁾	dB(A)	Hi:49 Lo:43	55	
Ext	erior dimensions		Unit 320 × 840 × 840	1050 × 000 × 240	
Н	$\mathbf{leight} imes \mathbf{Width} imes \mathbf{Depth}$	mm	Panel $30 \times 950 \times 950$	1250 × 920 × 340	
Net	weight	kg	36 (Unit:30 Panel:6)	107	
Ref	rigerant equipment		_	GU-A5560HS41 × 1	
С	Compressor type & Q'ty			GG-A330011341 × 1	
	Motor	kW	-	3.75	
	Starting method		-	Line starting	
Н	leat exchanger		Louver fins & inner grooved tubing	Slitted fins & bare tubing	
R	Refrigerant control		Capilla	ary tube	
Ref	rigerant		R407C		
C	Quantity	kg	-	2.58 [Pre-charged up to the piping length of 5m	
Ref	rigerant oil	Q.	-	1.6 (MA32)	
Def	rost control		MC contro	lled de-icer	
Hig	h pressure control		High press	sure switch	
Air	handling equipment		Turbo fan × 1	Describer for v. 2	
F	an type & Q'ty		Turbo fall × f	Propeller fan × 2	
	Motor	W	130×1	65×2	
	Starting method		Line starting	Line starting	
Α	Air flow (Standard)	СММ	Hi:28 Lo:20	110	
F	resh air intake		Available	-	
Α	air filter, Q'ty		Long life filter ×1(washable)	-	
Sho	ck & vibration absorber		Rubber sleeve (for fan motor)	Rubber mount (for compressor)	
Elec	ctric heater	W	-	40 (Crank case heater)	
Оре	eration control				
C	Operation switch		Wireless remote control switch	– (Indoor unit side)	
Roo	om temperature control		Thermostat by electronics	-	
Saf	ety equipment		Internal thermostat for fan motor.	Internal thermostat for fan motor.	
			Frost protection thermostat.	Abnormal discharge temperature protection. High pressure switch for protection.	
Ins	tallation data	mm		One lines 140 05 (0/4")	
В	Refrigerant piping size	(in)	Liquid line: φ9.52 (3/8") Gas line: φ19.05 (3/4")		
	Connecting method		Flare	piping	
D	Orain hose		(Connectable with VP25)	-	
Ir	nsulation for piping		Necessary (both L	iquid & Gas lines)	
Acc	essories		Mounting kit. Wireless rer	note controller. Drain hose	
Ont	ional parts		Decorati	ive Panel	

Notes (1) The data are measured at the following conditions.

Item	Indoor air t	emperature	Outdoor air	Standards	
Operation	DB	WB	DB	WB	Stalldards
Cooling	27°C	19°C	35°C	24°C	ISO-T1, JIS B8616
Heating	20°C	-	7°C	6°C	130-11, 113 150010


- (2) This packaged air-conditioner is manufactured and tested in conformity with the following standard. ISO-T1 "UNITARY AIR-CONDITIONERS"
- (3) The operation data indicate when the air-conditioner is operated at 380/415V 50Hz.
- (4) Indicates the value at mild mode.

11.2.2 Range of usage & limitations


Models	FDT(N)308~508 FDTNP308~508	FDTN258			
Indoor return air temperature (Upper, lower limits)	Refer to the selection chart				
Outdoor air temperature (Upper, lower limits)	Refer to the selection chart				
Indoor unit atmosphere (behind ceiling) temperature and humidity	Dew point temperature: 28°C or less, relative humidity: 80% or less				
Refrigerant line (one way) length	Max. 50m	Max. 30m			
Vertical height difference between outdoor unit and indoor unit	Max. 30m (Outdoor unit is higher) Max. 15m (Outdoor unit is lower)	Max. 15m			
Power source voltage	Rating	± 10%			
Voltage at starting	Min. 85% of rating				
Frequency of ON-OFF cycle	Max. 10 times/h				
ON and OFF interval	Max. 3	minutes			

11.2.3 Exterior dimensions

Models FDTN258H, 308H FDT308-A





Models FDTN408H, 508H FDT408-A, 508-A




(2) Remote controller

(a) Wireless remote controller





Indication board of indoor unit





(b) Wired remote controller


Unit: mm

Unit: mm

Remote controller mounting dimensions







Allowable rang of wire thickness and length


Standard Within 0.3 mm² × Within 100 m 0.5 mm² × Within 200 m 0.75 mm² × Within 300 m 1.25 mm² × Within 400 m 2 mm² × Within 600 m

Note (1) Allowable length of remote controller cable: 600 m


(3) Outdoor unit

Models FDC308HEN3B, 308HES3B FDCP308HEN3B, 308HES3B

Unit: mm



Required space for maintenance and air flow



Minimum allowable space to the obstacles


			Unit:mm
Installation type Mark	I	П	Ш
L_1	Open	Open	500
L ₂	300	5	Open
L ₃	100	150	100
L ₄	5	5	5

Notes


- (1) Avoid the location where four sides are entirely surrounded by walls.
- Fix the unit by anchor bolts without fail. Restrict the protrusion length of anchor bolt to 15 mm and under. When strong wind blows against the unit, direct the
- discharge port at a right angle to the wind direction.
- Secure the space of 1 m and over at the top of unit.
- Make the height of obstruction wall in front of discharge port lower than the height of unit.

Models FDC408HES3B, 508HES3B FDCP408HES3B, 508HES3B

Unit: mm



Required space for maintenance and air flow



Minimum allowable space to the obstacles

			Unit:mm
Installation type Mark	I	П	Ш
Lı	Open	Open	500
L_2	300	5	Open
L ₃	150	300	150
L4	5	5	5


Notes

- (1) Avoid the location where four sides are entirely sur-
- rounded by walls.


 (2) Fix the unit by anchor bolts without fail. Restrict the protrusion length of anchor bolt to 15 mm and under.

 (3) When strong wind blows against the unit, direct the discharge port at a right angle to the wind direction.
- (4) Secure the space of 1 m and over at the top of unit.
- (5) Make the height of obstruction wall in front of discharge port lower than the height of unit.

Models FDC256HEN3A, 256HEP3A



Required space for maintenance and air flow



Minimum allowable space to the obstacles


Installation type I II	m
Mark	
L ₁ Open 100	
L ₂ 100 Open	
L ₃ 100 500	

- Notes
 (1) Fix the unit with anchor bolts.
- (1) Fix the unit with alcold boths.(2) Strong wind must not be directed to the air outlet.(3) Free space over the unit must be larger than
- 1 m.
- 1 m.

 4) The unit should not be surrounded by obstructions in all direction.
 At least one direction around the unit must be free.

11.2.4 Exterior appearance


(1) Indoor unit Models All models




Туре	Item	Panel model	Remarks
For wireless remote controller	FDTN258H~508H FDTNP308H~508H	TN-PSC-32W-E	
For wired remote controller	FDT308-A~508-A	T-PSA-32W-E	With Auto swing

(2) Outdoor unit


Models FDC308HEN3B,308HES3B FDCP308HEN3B,308HES3B



Models FDC408HES3B, 508HES3B FDCP408HES3B, 508HES3B




Models FDC256HEN3A,256HEP3A




11.2.5 Piping system


Models FDTNP308HEN-SB, 308HES-SB, 408HES-SB FDTN308HEN-SB, 308HES-SB, 408HES-SB FDT308HEN-SB, 308HES-SB, 408HES-SB



Models FDTNP508HES-SB, FDTN508HES-SB, FDT508HES-SB



Models FDTN258HEN-A, 258HEP-A



Preset point of the protective devices


Parts name	Mark	Equipped unit	FDTN308~508 FDT308~508	FDTNP308~508	FDTN258
Thermistor (for protection over- loading in heating)	Th⊦R	Indoor unit	OFF 68°C ON 61°C		
Thermistor (for frost prevention)			OFF 2.5°C ON 10°C		
Thermistor (for detecting dis- charge pipe temp.)	Tho-D	Outdoor unit	OFF 135°C ON 90°C		
Thermistor (for detecting heat exchange temp.)	Tho-R	Outdoor unit	OFF 70°C ON 60°C		
Dfrost thermostat	23DH2 23DH1	Outdoor unit			OFF 12°C ON -6°C
High pressure switch (for controlling FM ₀)	63H ₂	Outdoor unit	OFF 2.50MPa ON 2.06MPa	OFF 2.79MPa ON 2.26MPa	OFF 2.50MPa ON 1.86MPa
High pressure switch (for protection)	63H₁	Outdoor unit		OFF 3.24MPa ON 2.65MPa	


11.2.6 Selection chart

Correct the cooling and heating capacity in accordance with the conditions as follows. The net cooling and heating capacity can be obtained in the following way.

Net capacity = Capacity shown on specification × Correction factors as follows.


(1) Coefficient of cooling and heating capacity in relation to temperatures





Outdoor air W.B. temperature (°CW.B.)

FDTN258HEN-A



Outdoor air W.B. temperature (°CW.B.)

FDTN258HEP-A




Table of bypass factor

Item	Model	258 models	308 models	408 models	508 models
Air flow	Hi	0.050	0.065	0.076	0.025
Air now	Lo	0.030	0.030	0.050	0.013

(2) Correction of cooling and heating capacity in relation to air flow rate control (fan speed) Coefficient: 1.00 at High, 0.95 at Low

(3) Correction of cooling and heating capacity in relation to one way length of refrigerant piping

It is necessary to correct the cooling and heating capacity in relation to the one way equivalent piping length between the indoor and outdoor units.

Equivaler	nt piping length ⁽¹⁾ m	7.5	10	15	20	25	30	35	40	45	50	55
Heating		1.0	1.0	1.0	1.0	1.0	0.998	0.998	0.993	0.993	0.988	0.988
	FDTN258	1.0	0.998	0.993	0.988	0.983	0.978	0.973	-	-	-	_
G 1'	FDTNP, FDT(N)308	1.0	0.995	0.985	0.975	0.965	0.955	0.945	0.935	0.925	0.915	0.905
Cooling	FDTNP, FDT(N)408	1.0	0.998	0.990	0.985	0.975	0.970	0.960	0.955	0.945	0.940	0.930
	FDTNP, FDT(N)508	1.0	0.995	0.980	0.970	0.955	0.945	0.930	0.920	0.905	0.895	0.880

Note (1) Equivalent piping length can be obtained by calculating as follows. $258, 308 \text{ series } [\phi 15.88(5/8'')]: \text{ Equivalent piping length} = \text{Real piping length} + (0.10 \times \text{Number or bends in piping})$ $408, 508, \text{ series } [\phi 19.05(3/4'')]: \text{ Equivalent piping length} = \text{Real piping length} + (0.15 \times \text{Number of bends in piping})$ [Equivalent piping length < Limitation length of piping + 5m]

(4) When the outdoor unit is located at a lower height than the indoor unit in cooling operation and when the outdoor unit is located at a higher height than the indoor unit in heating operation, the following values should be subtracted from the values in the above table.

Height difference between the indoor unit and outdoor unit in the vertical height difference	5m	10m	15m	20m	25m	30m
Adjustment coefficient	0.01	0.02	0.03	0.04	0.05	0.06


Piping length limitations

Model	FDTN(P)308~508 FDT308~508	FDTN258
Max. one way piping length	50m	30m
Max. vertical height difference	Outdoor unit is higher 30m Outdoor unit is lower 15m	15m

Note (1) Values in the table indicate the one way piping length between the indoor and outdoor units.

How to obtain the cooling and heating capacity

Example: The net cooling capacity of the model FDT308HEN-SB with the air flow "High", the piping length of 15m, the outdoor unit located 5m lower than the indoor unit, indoor wet-bulb temperature at 19.0 °C and outdoor dry-bulb temperature 35 °C is



11.2.7 Noise level

Notes (1) The data are based on the following conditions.

Ambient air temperature:


Indoor unit 27°C DB, 19°C WB.

Outdoor unit 35°C DB.

Indoor unit

Measured based on JIS B 8616

Mike position as below



Outdoor unit

Measured based on JIS B 8616

Mike position: at highest noise level

in position as below


Distance from front side Height 1 m

- (2) The data in the chart are measured in an unechonic room.
- (3) The noise levels measured in the field are usually higher than the data because of reflection.


(1) Indoor unit

Model FDTN258H

Noise level 39 dB (A) at HIGH 35 dB (A) at LOW





Models FDTN(P) 308H, FDT308-A



500

Models FDTN(P)408H, FDT408-A







(2) Outdoor unit

125


Models FDTN(P) 508H, FDT508-A

Noise level 49 dB (A) at HIGH 43 dB (A) at LOW







e band frequency (Hz)




FDC408HES3B FDCP408HES3B Models




Models FDC508HES3B FDCP508HES3B



Model FDC256HEN3A




Model FDC256HEP3A



11.3 ELECTRICAL DATA

11.3.1 Electrical wiring



Meaning of marks	narks		
Mark	Parts name	Mark	Parts name
ပ္ပ	Capacitor for CM	Th-A	Thermistor
Ę.	Capacitor for FMI	T H-H	Thermistor
မှိ	Capacitor for FMo	Tho-A	Thermistor
ᆼ	Crankcase heater	Tho-D	Thermistor
CM	Compressor motor	Tho-R	Thermistor
CnA ~ W	Connector (mark)	Ē	Transformer (Indoor unit)
5	Current sensor	Ē	Transformer (Outdoor unit)
ш	Fuse	Val	Varistor
Ē	Fan motor (Indoor unit)	Vao	Varistor
EM∘	Fan motor (Outdoor unit)	20S	4-way valve solenoid
Z	Louver motor	49Fı	Internal thermostat for FM1
rs	Limit switch	49Fo	Internal thermostat for FMo
Æ	Surge suppressor	22C	Magnetic contactor for CM
ပ	Photo coupler	X1~7	Auxiliary relay
SV1,2	Solenoid coil (for control)	X01~8	Auxiliary relay
SW1	Switch (Address set)	63H ₂	High pressure switch (for control)
SW2, 3	Changeover switch	\vee	Terminal (F)
P	Terminal block (O mark)	-	Connector
DM	Drain motor	LED-G	Indication lamp (Green)
S	Float switch	LED-R	Indication lamp (Red)
The	Thermistor		

Power source 1 Phase 220/240V 50Hz

Model FDT308HES-SB

Printed circuit board 888 888 Indoor unit N9/A ِ چ LED-R **A OnE (Checker) Outdoor unit SV₂ BK SR Power source 3 Phase 380/415V 50Hz ПЯ BE WHAT SEE THE SEE TH

Color	Black/Red Black/White Blue/White Brown/White Orange/White Red/White Yellow/Green
Mark	BK/RD BK/WH BL/WH BR/WH OR/WH RD/WH Y/GN
Color	Black Blue Brown Gray Orange Pink Red White
Mark	BR BR GR PP RD WH

Meaning of marks	narks		
Mark	Parts name	Mark	Parts name
Ę	Capacitor for FMI	Thi-A	Thermistor
CFo	Capacitor for FMo	무무	Thermistor
ᇙ	Crankcase heater	Tho-A	Thermistor
S	Compressor motor	Tho-D	Thermistor
CnA~Z	Connector (mark)	Tho-R	Thermistor
CT _{1.2}	Current sensor	Ē	Transformer (Indoor unit)
ш	Fuse	<u>آ</u>	Transformer (Outdoor unit)
ΕM	Fan motor (Indoor unit)	Val	Varistor
FMo1	Fan motor (Outdoor unit)	Vao	Varistor
Z	Louver motor	20S	4-way valve solenoid
rs	Limit switch	49Fı	Internal thermostat for FM1
Æ	Surge suppressor	49F 0₁	Internal thermostat for FMo
DΜ	Drain motor	25C	Magnetic contactor for CM
S	Float switch	X1~7	Auxiliary relay
ည	Photo coupler	X _{01~08}	Auxiliary relay
SV _{1,2}	Solenoid coil (for control)	63H ₂	High pressure switch (for control)
SW1	Switch (Address set)	\vee	Terminal (F)
SW2, 3	Changeover switch	-	Connector
1 B	Terminal block (O mark)	LED-G	Indication lamp (Green)
Thc	Thermistor	LED-R	Indication lamp (Red)

Models FDT408HES-SB, 508HES-SB

circuit board ON SW2 OFF ON SW3 OFF OFF Printed 888 888 Indoor unit Outdoor unit BK BK RnO ПЯ

 Color mark
 Color

 Mark
 Color
 Mark
 Color

 BL
 Black
 BKMH
 Black/Red

 BR
 Brown
 Black/White

 GR
 Gray
 BL/WH
 Black/White

 GR
 Gray
 BR/WH
 Brown/White

 OR
 Orange
 ORWH
 Conge/White

 P
 Pink
 Red
 Y/GN
 Yellow/Green

 WH
 White
 Y/GN
 Yellow/Green

		-	
Mark	Parts name	Mark	Parts name
Ŗ	Capacitor for FMI	Thi-A	Thermistor
CF 01,2	Capacitor for FMo	Th-R	Thermistor
ᆼ	Crankcase heater	Tho-A	Thermistor
S	Compressor motor	Tho-D	Thermistor
CnA~Z	Connector (mark)	Tho-R	Thermistor
CT _{1,2}	Current sensor	Ē	Transformer (Indoor unit)
ш	Fuse	Į.	Transformer (Outdoor unit)
Ē	Fan motor (Indoor unit)	Val	Varistor
FM01,2	Fan motor (Outdoor unit)	Vao	Varistor
Z	Louver motor	20S	4-way valve solenoid
rs	Limit switch	49Fı	Internal thermostat for FMI
æ	Surge suppressor	49F01,2	Internal thermostat for FMo
M	Drain motor	25C	Magnetic contactor for CM
Z.	Float switch	X1~7	Auxiliary relay
ည	Photo coupler	X01~08	Auxiliary relay
SV _{1,2}	Solenoid coil (for control)	63H ₂	High pressure switch (for control)
SW1	Switch (Address set)	\vee	Terminal (F)
SW2,3	Changeover switch	-	Connector
B	Terminal block (O mark)	LED-G	Indication lamp (Green)
J	Thermistor	LED-R	Indication lamp (Red)

Meaning of marks

Power source 3 Phase 380/415V 50Hz


FDTNP308HEN-SB **B B** CnV Printed circuit board ON SW2 112134 OF 0N SW3 112134 OFF (2) Indoor Unit 388 388 BR/WH TB BR/WH (1) SH/MH (2) SH/MH (3) SH/MH (4) SH/MH (5) SH/MH (BK W **Outdoor Unit** SV₂ 18 N SV1 ਙ₽ਛ 88 88 RuD BK BK Power source 1 Phase 220/240V 50Hz BENNH Printed circuit board HW HW TB RD 52C (I) NS/A

Models FDTN308HEN-SB

Note (1) $\%1~63\text{H}_1$ is equipped with only for FDTNP type.

Meaning of marks	narks			Color mark	
Mark	Parts name	Mark	Parts name	Mark	
သ	Capacitor for CM	Thi-A	Thermistor	¥	В
Ē	Capacitor for FM1	Th-R	Thermistor	В	М
cF _o	Capacitor for FMo	Tho-A	Thermistor	BB	М
팡	Crankcase heater	Tho-D	Thermistor	g.	Ö
CM	Compressor motor	Tho-R	Thermistor	OR B	0
CnA ~ W	Connector (mark)	Ē	Transformer (Indoor unit)	¥	Δ
Ę	Current sensor	Ţ.	Transformer (Outdoor unit)	2	~
ш	Fuse	Val	Varistor	¥	=
Ē	Fan motor (Indoor unit)	Vao	Varistor	>	>
EM o	Fan motor (Outdoor unit)	20S	4-way valve solenoid		
LED1	Indication lamp (Green - Run)	49Fi	Internal thermostat for FM1		
LED2	Indication lamp (Yellow - Timer/Check)	4 9F o	Internal thermostat for FMo		
Z	Louver motor	52C	Magnetic contactor for CM		
Æ	Surge suppressor	X1~7	Auxiliary relay		
ဥ	Photo coupler	X01~8	Auxiliary relay		
SV _{1,2}	Solenoid coil (for control)	63H1	High pressure switch (for protection)		
SW	Switch (ON/OFF)	63H ₂	High pressure switch (for control)		
SW2, 3	Changeover switch	∇	Terminal (F)		
<u>1</u>	Terminal block (O mark)	-	Connector		
Σ	Drain motor	LED-G	Indication lamp (Green)		
FS	Float switch	LED-R	Indication lamp (Red)		

Mark	Color	Mark	Color
BK	Black	BK/RD	Black/Red
Я	Blue	BKWH	Black/White
8	Brown	BLWH	Blue/White
85	Gray	BR/WH	Brown/White
В	Orange	OR/WH	Orange/White
¥	Pink	RD/WH	Red/White
2	Red	Y/GN	Yellow/Green
¥	White		
Υ.	Yellow		




Note (1) *1 63H1 is equipped with only for FDTNP type.

Meaning of marks

Mark	Color	Mark	Color
æ	Black	BK/RD	Black/Red
ВГ	Blue	BKWH	Black/White
BB	Brown	BLWH	Blue/White
GR	Gray	BRWH	Brown/White
OR	Orange	OR/WH	Orange/White
<u>م</u>	Pink	RD/WH	Red/White
2	Red	X/GN	Yellow/Green
ΗM	White		

Mark	Parts name	Mark	Parts name
CFi	Capacitor for FMI	Tho-A	Thermistor
CF ₀₁	Capacitor for FMo	Tho-D	Thermistor
귱	Crankcase heater	Tho-R	Thermistor
S	Compressor motor	Ē	Transformer (Indoor unit)
CnA ~ Z	Connector (mark)	일	Transformer (Outdoor unit)
CT _{1,2}	Current sensor	Val	Varistor
ш	Fuse	Vao	Varistor
Ē	Fan motor (Indoor unit)	20S	4-way valve solenoid
FM ₀₁	Fan motor (Outdoor unit)	49Fı	Internal thermostat for FMI
Z	Louver motor	49F01	Internal thermostat for FMo
Æ	Surge suppressor	22C	Magnetic contactor for CM
M	Drain motor	X1~7	Auxiliary relay
ភ	Float switch	X01~08	Auxiliary relay
ပ	Photo coupler	63H1	High pressure switch (for protection)
SV _{1,2}	Solenoid coil (for control)	63H ₂	High pressure switch (for control)
SW	Switch (ON/OFF)	\vee	Terminal (F)
SW2, 3	Changeover switch	-	Connector
TB	Terminal block (O mark)	LED-G	Indication lamp (Green)
Th-A	Thermistor	LED-R	Indication lamp (Red)
Th-R	Thermistor		

Models FDTN408HES-SB, 508HES-SB FDTNP408HES-SB, 508HES-SB



Note (1) 41 63H1 is equipped with only for FDTNP type.

Meaning o sf marks

Color mark			
Mark	Color	Mark	Color
BK	Black	BK/RD	Black/Red
В	Blue	BKWH	Black/White
BB	Brown	BLWH	Blue/White
GR	Gray	BR/WH	Brown/White
OR	Orange	OR/WH	Orange/White
<u>م</u>	Pink	RD/WH	Red/White
22	Red	Y/GN	Yellow/Green
¥	White		

Mark	Parts name	Mark	Parts name
Ę	Capacitor for FM1	Tho-A	Thermistor
CF01,2	Capacitor for FMo	Tho-D	Thermistor
ᇙ	Crankcase heater	Tho-R	Thermistor
CM	Compressor motor	Ē	Transformer (Indoor unit)
CnA~Z	Connector (mark)	길	Transformer (Outdoor unit)
CT _{1,2}	Current sensor	Val	Varistor
ш	Fuse	Vao	Varistor
Ē	Fan motor (Indoor unit)	20S	4-way valve solenoid
FM _{01,2}	Fan motor (Outdoor unit)	49Fi	Internal thermostat for FMI
Z	Louver motor	49F01,2	Internal thermostat for FMo
æ	Surge suppressor	25C	Magnetic contactor for CM
Σ	Drain motor	X1~7	Auxiliary relay
ស	Float switch	X01~08	Auxiliary relay
ပ	Photo coupler	63H1	High pressure switch (for protection)
SV _{1,2}	Solenoid coil (for control)	63H ₂	High pressure switch (for control)
SW	Switch (ON/OFF)	\vee	Terminal (F)
SW2,3	Changeover switch	-	Connector
P	Terminal block (O mark)	LED-G	Indication lamp (Green)
Th⊦A	Thermistor	LED-R	Indication lamp (Red)
늄	Thermistor		

Models FDTN258HEN-A, 258HEP-A

Printed wiring board ON SW2 11234 OFF ON SW3 1234 8 8 8 8 8 8 8 Indoor Unit Outdoor Unit FB . 158 ま ChP ᆼ Power source FDTN258HEN-A 1 Phase 220/240V 50Hz FDTN258HEP-A 1 Phase 220V 60Hz - NR 1 K/GN

Mark	Color
	Black
	Blue
	Brown
	Gray
	Orange
	Red
	White
ND/A	Yellow/Green

Color mark

Mark	Parts name	Mark	Parts name
ပ္ပ	Capacitor for CM	Thi-A	Thermistor
Ē	Capacitor for FMI	Th-R	Thermistor
Ę,	Capacitor for FMo	Ξ	Transformer
공	Crankcase heater	Val	Varistor
CM	Compressor motor	20S	4-way valve solenoid
CnA ~ W	Connector (mark)	23DH	Thermostat (deicer)
ΣQ	Drain motor	49C	Internal thermostat for CM
ш	Fuse	49Fi	Internal thermostat for FM1
Ē	Fan motor (Indoor unit)	49Fo	Internal thermostat for FMo
FMo	Fan motor (Outdoor unit)	25C	Magnetic contactor for CM
Z.	Float switch	52Fo	Relay for FMo
LED1	Indication lamp (Green - Run)	22X0	Relay for fan control
LED2	Indication lamp (Yellow - Timer/Check)	X1~7	Auxiliary relay
Z	Louver motor	63H ₂	High pressure switch (for control)
rs	Limit switch	∇	Terminal (F)
Æ	Surge suppressor	•	Connector
S.	Photo coupler		
SW	Switch (ON/OFF)		
SW2, 3	Changeover switch		

11.4 OUTLINE OF OPERATION CONTROL BY MICROCOMPUTER

This is same as FDUR heat pump series. Refer to page 306.

11.5 APPLICATION DATA SAFETY PRECAUTIONS

- Please read these "Safety Precautions" first then accurately execute the installation work.
- Though the precautionary points indicated herein are divided under two headings. AWARNING and ACAUTION, those points which are related to the strong possibility of an installation done in error resulting in death or serious injury are listed in the AWARNING section. However, there is also a possibility of serious consequences in relationship to the points listed in the ACAUTION section as well.

In either case, important safety related information is indicated, so by all means, properly observe all that is mentioned.

• After completing the installation, along with confirming that no abnormalities were seen from the operation tests, please explain operating methods as well as maintenance methods to the user (customer) of this equipment, based on the owner's manual.

Moreover, ask the customer to keep this sheet together with the owner's manual.

AWARNING

- This system should be applied to places of office, restaurant, residence and the like. Application to inferior environment such as engineering shop could cause equipment malfunction.
- Please entrust installation to either the company which sold you the equipment or to a professional contractor. Defects from improper installations can be the cause of water leakage, electric shocks and fires.
- Execute the installation accurately, based on following the installation manual. Again, improper installations can result in water leakage, electric shocks and fires.
- When a large air-conditioning system is installed to a small room, it is necessary to have a prior planned countermeasure for the rare case of a refrigerant leakage, to prevent the exceeding of threshold concentration. In regards to preparing this countermeasure, consult with the company from which you perchased the equipment, and make the installation accordingly. In the rare event that a refrigerant leakage and exceeding of threshold concentration does occur, there is the danger of a resultant oxygen deficiency accident.
- For installation, confirm that the installation site can sufficiently support heavy weight. When strength is insufficient, injury can result from a falling of the unit.
- Execute the prescribed installation construction to prepare for earthquakes and the strong winds of typhoons and hurricanes, etc. Improper installations can result in accidents due to a violent falling over of the unit.
- For electrical work, please see that a licensed electrician executes the work while following the safety standards related to electrical equipment, and local regulations as well as the installation instructions, and that only exclusive use circuits are used.
- Insufficient power source circuit capacity and defective installment execution can be the cause of electric shocks and fires.
- Accurately connect wiring using the proper cable, and insure that the external force of the cable is not conducted to the terminal connection part, through properly securing it. Improper connection or securing can result in heat generation or fire.
- Take care that wiring does not rise upward, and accurately install the lid/service panel. Its improper installation can also result in heat generation or fire.
- When setting up or moving the location of the air-conditioner, do not mix air etc. or anything other than the designated refrigerant within the refrigeration cycle.
- Rupture and injury caused by abnormal high pressure can result from such mixing.
- Always use accessory parts and authorized parts for installation construction. Using parts not authorized by this company can result in water leakage, electric shock, fire and refrigerant leakage.

ACAUTION

- Execute proper grounding. Do not connect the ground wire to a gas pipe, water pipe, lightning rod or a telephone ground wire. Improper placement of ground wires can result in electric shock.
- The installation of an earth leakage breaker is necessary depending on the established location of the unit. Not installing an earth leakage breaker may result in electric shock.
- Do not install the unit where there is a concern about leakage of combustible gas.
 The rare event of leaked gas collecting around the unit could result in an outbreak of fire.
- For the drain pipe, follow the installation manual to insure that it allows proper drainage and thermally insulate it to prevent condensation. Inadequate plumbing can result in water leakage and water damage to interior items.

11.5.1 Installation of indoor unit

⚠NOTICE

All Wiring of this installation must comply with NATIONAL, STATE AND LOCAL REGULATIONS. These instructions do not cover all variations for every kind of installation circumstance. Should further information be desired or should particular problems occur, the matter should be referred to Mitsubishi Heavy Industries, Ltd. through your local distributor.


∆WARNING

BE SURE TO READ THESE INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD CAUSE SERIOUS INJURY OR DEATH, EQUIPMENT MALFUNCTION AND/OR PROPERTY DAMAGE.

(1) Selection of installation location

- (a) Select location where the space above ceiling is larger than those mentioned below and perfect draining can be assured.
- (b) Places where perfect drainage can be prepared and sufficient drainage gradient is available.
- (c) Places free from air distrubances to the air inlet and outlet of the indoor unit.
- (d) laces with the environmental dew-point temperature is lower than 28°C and the relative humidity is less than 80%. (When installing at a place under a high humidity environment, pay sufficient attention to prevention of dewing such as thermally insulating the unit properly.)
- (e) Do not place where the unit is exposed to oil splashes or steam (e.g. kitchens and machine plants). (Installation and use at such places will causes the performance drop, corrosion in the heat exchanger and damage in molded synthetic resin parts.)
- (f) Do not place where corrosive gas (such as sulfurous acid gas) or inflammable gas (thinner, gasoline, etc.) is generated or remains. Installation and use at such places will cause corrosion in the heat exchanger and damage in molded synthetic resin parts.
- (g) Do not place adjacent to equipment generating electromagnetic waves or high-frequency waves such as in hospitals,
 - Generated noise may cause malfunctioning of the controller.


Model	Space above ceiling
258, 308	Over 270 mm
408, 508	Over 330 mm



(2) Preparation for installation

- (a) Ceiling hole size and Position of suspension bolts.
 - 1) The pattern sheet may shrink or expand as humidity changes, so check the actual size before use.
 - 2) The size of ceiling opening can be adjusted within the range shown below. Bring the unit body to the ceiling opening right in the center so as not to be set aside and so that space between a ceiling opening end and the outside of the unit body becomes equal to that on the opposite side.
 - 3) The size of the pattern sheet equals to the maximum size of the square ceiling opening.
- (b) Location of Pipes

For the location of pipe, see the exterior dimension.



A	Gas refrigerant piping
В	Liquid refrigerant piping
C	Drain piping connecting hole
D	Power intake hole
Е	Hang bolt
F	Outside air intake hole
G	Supply air branch duct connecting hole


	Un	it: mm
Model	a	b
258, 308	210	260
408, 508	270	320

(3) Hanging

 Arrange four sets of a hang bolt (M10 or M8), a nut for it, a plain washer and a spring washer on site.

When there is the ceiling


- Make an 860 to 890 mm-square cutout on the ceiling.
 Refer to the outside dimensions of packing cardboard container.
 Align the center of ceiling cutout and the center of unit.
- Decide the hang bolt position 675×780 in the case of FDT(N) 258 ~ 508.
- 3. Use four hang bolts and fix them so that each bolt can resist the pull out load of 50kgf.
- 4. Decide the length of hang bolt to approx. 70mm above the ceiling surface.
- 5. After hanging in the unit, fix the attached level gauge and secure the height of unit.
- 6. Use a transparent hose filled with water to check the levelness of unit. (The maximum allowable height difference between both ends of unit is 3mm.)




(4) Drain Piping

(a) Drain piping should always be in a downhili grade (1/50~1/100) and avoid riding across and elevation or making traps.


Good piping




Improper piping



- (b) When connecting the drain pipe to unit, pay sufficient attention not to apply excess force to the piping on the unit side. Also, fix the piping at a point as close as possible to the unit.
- (c) For drain pipe, use hard PVC general purpose pipe VP-25 (I.D.1") which can be purchased locally. When connecting, insert a PVC pipe end securely into the drain socket before tightening securely using the attached drain hose and clamp. Adhesive must not be used connection of the drain socket and drain hose (accessory).
- (d) When consturcting drain piping for several units, position the common pipe about 100 mm below the drain outlet of each unit as shown in the sketch. Use VP-30 (11/4") or thicker pipe for this purpose.
- (e) Be sure to provide heat insulation to hard PVC pipes of indoor placement.
- (f) Do not ever provide an air vent.
- (g) The height of the drain head can be elevated up to a point 700 mm ablve the ceiling and, when an obstacle exists in the ceiling space, elevate the piping to avoid the obstacle using an elbow or corresponding gadget. When doing this, if the stretch for the needed height is too high, the back-flow quantity of drain at the event of interruption of the operation gets too much and it may cause overflow at the drain pan. Therefore, make the height of the drain pipe within the distance given in the sketch below.
- (h) Avoid positioning the drain piping outlet at a place where generation of odor may be stimulated. Do not lead the drain piping direct into a sewer from where sulfur gas may generate.
- (i) The purpose of drain hose is to absorb minute discrepancy of the unit or the drain piping occurred when they are installed. Therefore, when it is bent intentionally or used under expanded condition, it may be damaged and result in water leakage.






Drainage Test

- ① Conduct a drainage test after completion of the electrical work.
- ② During the trial, make sure that drain flows properly through the piping and that no water leaks from connections.
- (3) In case of a new building, conduct the test before it is furnished with the ceiling.
- 4) Be sure to conduct this test even when the unit is installed in the heating season.

Procedures

① Supply about 1000 cc of water to the unit through the air outlet by using a feed water pump.



If the electrical work has not been completed, connect a convex joint in the drain pipe connection to provide a water inlet.

Then, check if water leaks from the piping system and that drain flows through the drain pipe normally.

- 2 Check at the exhaust port if drain is flowing.
 - (Note) Conduct this test paying attention to rotating sound of the drain motor.
- (3) Remove the drain plug located on the bottom of the drain pan when the water has to be evacuated from the unit.
- 4 After the test, fit the drain plug to the original place and turn off the power source.

(5) Fixing of Decorative Panel (The panel fixing bolts are attached on the panel.)


- (a) Check with the accessory level gauges that the indoor unit height and the size of ceiling hole are correct.
 - Remove the level gauges from the indoor unit before fixing the decorative panel.
- (b) Screw two bolts out of four accessory bolts less than 5 mm in the indoor unit diagonally.
- (c) Hang the panel on the two bolts and fix them temporarily.
- (d) Tighten the bolts fixed temporarily and the ramaining two bolts.
 - Screw the remaining two bolts, and tighten all (four) bolts.
- (e) Connect the louver motor connector (red) to the panel respectively.
- (f) If the louver motor is not operated by remote control, check if the connector is connected correctly, and turn off the power for more then 10 seconds, then reset it.


Panel Joint Setting

 The panel can turn 30 mm to the left and to the right in all, and the indoor unit turns 30 mm to the left and to the right in all in the case of FDT(N)258~508.

Limit Fixing Panel

- ① Fix the panel only in the direction shown in the figure.
- ② If it is fixed in other way, air will leak. Also, wires cannot be connected for auto swing and receiver amp.





(6) Cautions for wireless remote conntroller operation

As wireless remote controller is operated by infrared rays as a signal, make sure to explain to customers the following matters regarding the operating distance and protection from jamming.

- Operate it by directing the remote controller switch correctly to the receiver amp section.
- Operating distance is shown below, but it may become shorter or longer depending on circumstances.
- When its receiving section is directly under the sun or strong illumination, or covered by dust or behind an obstacle, the operating distance may become shorter or it may not work.
- A hook for fixing the remote controller is provided for to keep the controller from missing.

(a) Operating distance of wireless remote controller


Operate it within the distance and angle shown in the sketch.


1) Standard receiving distance

CONDITION: 300 luxes at the receiving section (at an ordinary office where there is no ceiling light within one meter around the unit.

The receiving distance as viewd from the plane, and the relation between the illumination at the receiving section and receiving distance.

CONDITION: The relation between illumination and receiving distance when the remote controller is operated at the place one meter above the floor with the ceiling 2.4 m high. When the illumination is doubled, the receiving distance become 2.3.





By switching the dip switch (SW3-3) on the indoor unit printed circuit board ("Specify the following switch number."), the operation mode can be changed to the quiet mode (mild mode). Confirm at installation and change if necessary.

11.5.2 Installation of remote controller

This is same as FDUR heat pump series. Refer to page 329.

11.5.3 Installation of outdoor unit

This is same as FDUR heat pump series. Refer to page 330.

11.6 MAINTENANCE DATA

This is same as FDUR heat pump series. Refer to page 340.

MEMO